

- ① In Etabs define all stories above BASE matchip with CAD plus an extra story at top. Set story ht = consistent.
- ② Open each dwg floor, move to origin, move to '2' level. Freeze un-necessary layers. Move remain to ETABS layer. Save as dxf.
- ③ Import as 3d one by one all floors. then. replicate/delete to floor above.
- ④ Draw accordig to CAD.
- ⑤ Delete un-necessary Lines. ~~del~~ replicate/delete to one story above. Delete extra stories. Set story ht.